






HOUSING

Poles	Receptacle housing (for pin contact)	Plug housing (for socket contact)
4	SM-4P 	SM-4R 
5	SM-5P 	SM-5R 
6	SM-6P 	SM-6R 